



Creme Eve'e E-bike Quick Start Guide



GETTING STARTED with Creme E-bike




- Charge your battery before you set off using supplied charger. It is best to charge fully or at least until the battery LED lights up.
- You can charge the battery off-bike using the supplied charger adapter.
- Switch the system ON by pressing the button on the battery.
- Select desired assist mode with the handlebar-mounted assist switch




- Go ride!
- Getting dark? To switch the lights ON press and hold the little button on the wireless controller for 2 seconds until the light switches on. Note that you cannot turn the light off while riding the bike.
- Pay attention to the LED light on the wireless controller. It will help you estimate battery level.



LED2 shows the battery level when the power is ON.

LED2 display	Battery level
 (lit up)	100 - 21%
 (lit up)	20% or less
 (flashing)	Nearly empty




- All our E-bikes are fitted with a wireless controller so that you can use E-TUBE RIDE app on your mobile phone to display current speed, assist mode, range and much more. For detailed instructions visit:

<https://e-tuberide.shimano.com>



- You may want to update the system firmware and customise some settings to your liking. You can do so using E-TUBE PROJECT application on your mobile phone. You will find download links and operating instructions at:

<http://e-tubeproject.shimano.com>



- Visit manufacturers website for all the information you need about the electric assist system used in your bike:

<https://www.shimano-steps.com>

- Check Shimano technical website for detailed user and dealer manuals:

<https://si.shimano.com/#/>