



# FRONT LAMP

user  
manual

**Features:** 20 lux illumination in beam center, splash and rain water proof, low battery indicator

**Battery:** 4 x AAA (included)

**Installation:** Attach the lights securely at the fork crown using M6 screw with locknut.

Before first use remove the isolating plastic strip.

**Operation:** switch the light on with the ON-OFF switch located on top of the housing.

The switch contains low battery indicator which flashes red when battery level is low.

**Battery replacement:** use screwdriver or coin to unscrew the safety bolt at the bottom of the light. Turn the front ring counter - clockwise to remove the reflector assembly and access battery tray. Replace batteries observing the battery position. Reassemble the front ring and turn it clockwise to lock. Don't forget to secure the safety screw.

Creme Front Lamp is approved according to German "StVZO" (K 1122).

The retro-reflector meets "StVZO" and is approved according ECE-R3 (IA-E1-02 4005).